

IMPORTANT NOTICE: RUBBERSHOX INSTALLERS SHOULD APPLY COMMON AUTOMOTIVE SAFETY PRACTICES WHEN RAISING, LOWERING AND WORKING ON VEHICLES, ALWAYS WEARING SAFETY GLASSES, USING BOTH HYDRAULIC JACK AND JACK STAND DURING THE INSTALLATION. We recommend that this installation be done by a professional or person with auto mechanical knowledge.



Customer only wants to install in the rear of the vehicle. He likes to go camping and will tow a small trailer and lots of stuff in the back seat. His SUV will tilt up after all the loading and he can't see the headlight at night. He wants to install buffers to support the back end.

CSBPro-B was select after measured the gap (lifted up the SUV) of his car. The swing bar is very close the rear coil spring and make the installation very difficult. We need to cut off the inner bottom ring to make the installation easier.

