

Installed Items : MUB12-LOAD

**IMPORTANT NOTICE:** INSTALLERS SHOULD APPLY COMMON AUTOMOTIVE SAFETY PRACTICES WHEN RAISING, LOWERING AND WORKING ON VEHICLES, ALWAYS WEARING SAFETY GLASSES, USING BOTH HYDRAULIC JACK AND JACK STAND DURING THE INSTALLATION. We recommend that this installation be done by a professional or person with auto mechanical knowledge. Universal Bump Stop are designed to work with original factory springs only. These instructions are general guide line. We assumes no liability for actual installation process. We does not recommend exceed the maximum load recommended by vehicles manufacturer (GVWR)



Original factory bump stop

