

Medium Universal Rubber Bump Stop Dimensions


Please contact us at Rubbershox.com/contact immediately if you have any questions about installing Medium Universal Rubber Bump Stop on your vehicle. We are a US company located in Southern California.

(Do not Copy) MUBS is Patent Pending. This instruction is part of an installation manual that is under Copyright Protection by RubberShox®
 WARNING: Customers require common automotive safety practices during the installations, we recommend installation be done by a professional mechanical knowledge. RubberShox® hold no liability for actual automotive safety practices.
 DISCLAIMER: RubberShox® Bump Stop products DO NOT increase vehicle load capacity. They are designed to equalize loads support OE suspension for more stability and increase ground clearance. Please refer to your vehicle's owner's manual for maximum load capacity for safe operation.

Model	MUB1	MUB2	MUB2F	MUB1A	MUB1B	MUB1C	MUB1D
Qty	2	2	2	2	2	2	2
Shore A Hardness	Shore 50±5 HA	Shore 50±5 HA	Shore 40±5 HA	Shore 50±5 HA	Shore 50±5 HA	Shore 50±5 HA	Shore 50±5 HA
50% Compression (lbf)	5000	4000	3000	5000	5000	5000	5000
Material	Natural Rubber	Natural Rubber	Natural Rubber	Natural Rubber	Natural Rubber	Natural Rubber	Natural Rubber

Model	Modular Combination			50% Compression (lbf)		Compatible Vehicle	Note
				Single	Pair		
MUB12	MUB1	MUB2		2,893	5,786	Toyota Tacoma, Nissan Frontier, Chevrolet Colorado, Ford Ranger, GMC Canyon	Not for loading or towing
MUB122	MUB1	MUB2	MUB2	2,731	5,462		
MUB1A2	MUB1A	MUB2		2,383	4,766	Suburban, Tahoe, Yukon, Avalanche, Escalade, Silverado 2500, 3500	
MUB1B2	MUB1B	MUB2		1,385	2,770	Jeep Wrangler JK, Chevrolet/GMC Express/Savana 1500 /2500 /3500 /4500, Silverado 3500, GMC Sierra 3500	
MUB1C2	MUB1C	MUB2		832	1,664	Jeep Wrangler JK/JKU front	
MUB1D2	MUB1D	MUB2		1,113	2,226	Chevrolet 1999-2006 Silverado 1500, 2007 Silverado 1500 Classic, GMC 1999-2006 Sierra 1500, 2007 Sierra 1500 Classic	

Top Modules (unit:inch)



Sub Modules (unit:inch)

